



ROUNDIT® 2000 NX Cutting Guide

This document provides the correct procedure for cold cutting Roundit 2000 NX.

Required Tools:

Scissors:

Roundit 2000 NX should be cut with good paper quality scissors. It is important to make sure that a gap does not exist between the blades of the scissors.



Correct Scissors



Unacceptable Scissors

Step 1:

Make one straight cut across the width of the product.



Step 2:

Using very light force, manually pull the loose fibers off the end of the cut edge.



Step 3:

Pull any remaining loose fiber over to tracer edge of the product. Filaments will stop unraveling—cut off with scissors.



NOTE: If initial cut is not straight (cut on an angle) repeat Step 1.

